




Velvet Drive Marine Transmission Service Manual Models 70C & 71C



Warner Gear

Division of Borg-Warner Corporation

SERVICE MANUAL
PRICE \$2.50

"VELVET DRIVE"[®]

HYDRAULIC TRANSMISSION



DIRECT DRIVE MODEL 70C & 71C SERIES

This Service Manual is prepared and illustrated for the ASI-70C and ASI-71C direct drive transmission, but it also contains supplementary information and illustrations which allow it to be used for the servicing of the other earlier model transmissions, ASI-70B, ASI-71B, ASI-70 and ASI-71.

Deniz Motor Temin A.Ş.
İbrahim Cemberci

Büyükdere, Korklar Sok. No. 7
İSTANBUL
Tel. 142 1017 - 142 61 61

REVİZYON 5 1984

Warner Gear



Division of Borg-Warner Corporation
P.O. Box 2688, Muncie, Indiana 47302
Telephone 317/286-6100 Telex 27-491

FORM 1137/11-83
PRINTED IN U.S.A.

TABLE OF CONTENTS

INSTALLATION DRAWINGS AND INFORMATION	5
CROSS SECTION ASSEMBLY DRAWINGS	6
EXPLODED VIEWS AND PARTS LISTS	12
CIRCULATION DIAGRAM	19
DESCRIPTION	20
INSTALLATION PRECAUTIONS	21
Transmission oil cooler	21
Control lever position	21
Front pump mounting	21
LUBRICATION RECOMMENDATIONS	21
Checking oil level	21
Changing oil	21
Transmission fluid	21
Oil capacity	21
TRANSMISSION OPERATION	22
Forward	22
Neutral	22
Reverse	22
Freewheeling	22
Oil pressures	22
DISASSEMBLY OF TRANSMISSION	24
Oil draining procedure	24
Disassembly of valve and spring assembly from transmission	24
Removal of front pump assembly	24
Removal of adapter and reverse clutch piston	25
Removal of thrust washer, reverse clutch pressure plate, pressure plate springs and dowel pins	25
Removal of drive gear and clutch assembly	25
Disassembly of forward clutch	25
Removal of pinion cage and output shaft assembly from transmission case	26
Removal of rear bearing	26
REASSEMBLY PRECAUTIONS	26
INSPECTION AND GENERAL INSTRUCTIONS	27
ASSEMBLY OF TRANSMISSION	27
Assembling oil seal in bearing retainer	27
Installation of baffle in the transmission case	28
Installation of pinion cage and output shaft assembly in the transmission case	28
Assembly of the forward clutch into the ring gear	31
Assembly of forward clutch hub and sealing rings on drive gears	34
Assembling drive gear and clutch assembly	35
Installation of drive gear and clutch assembly, reverse clutch plate, and reverse clutch pressure plate in transmission case	36
Assembly of reverse clutch piston into adapter	38
Assembly of adapter and reverse clutch piston onto transmission case	39
Assembly of front pump	40
Mounting front pump on transmission	41
Assembling valve spring assembly	42
Installation of the valve and spring assembly in the transmission case	43
Assembly of shift lever	44
Installation of oil strainer assembly and oil drain plug into transmission case	45
Installation of miscellaneous transmission parts	45

EXTRA EQUIPMENT	46
Assembly of neutral switch kit	46
SPECIAL INFORMATION AND INSTRUCTIONS – MODEL 70C AND 71C TRANSMISSIONS	47
Installation of oil filler cap and dipstick assembly	47
Installation of oil strainer assembly and oil drain plug into transmission case	47
Installation of breather assembly	48
Assembly of front pump	48
Mounting front pump on transmission	50
Elimination of regulator valve buzz	51
Drive gear and plug assemblies	52
Pinion cage and output shaft assembly	52
Forward and reverse gear transmission case and bushing assembly	52
SPECIAL INFORMATION AND INSTRUCTIONS – MODEL 70B AND 71B TRANSMISSIONS	53
Installation of breather assembly	53
Assembly of front pump	53
Drive gear and plug assembly	53
Assembly of shift lever	53
Adapter capscrews	54
SPECIAL INFORMATION AND INSTRUCTIONS – MODEL 70 AND 71 TRANSMISSIONS	54
Assembly of front pump	54
Installation of the baffle in the transmission case	54
Installation of oil strainer assembly and oil drain plug into transmission case	55
Cooler return to transmission	55
SERVICE INSTRUCTIONS FOR SERIES 10-17 AND 10-18 TRANSMISSIONS	56
TROUBLE SHOOTING CHART	58
BOLT TORQUE SPECIFICATIONS	60
ASSEMBLY TOOL DRAWINGS	61

*NOTE #3


SUBJECT: SEALING RINGS ADDED TO ALL IN-LINE AND V-DRIVE ASSEMBLIES

All Velvet Drive In-Line and V-Drive assemblies have been changed to use four 4806B cast iron sealing rings. New pinion cage and output shaft assemblies having four ring grooves for the sealing rings will be used in the forward and reverse portion of these assemblies. These new pinion cage and output shaft assemblies have a larger diameter; therefore the 71-159 thrust washer when used will be replaced by a new 10-17-193-001 thrust washer with a larger inside diameter.


The two bushings, which were pressed into the 1.989-1.990" (50.5-50.55 mm) bore at the rear of the forward and reverse transmission case are no longer required and will be removed. The case bore size will be changed to 2.000-2.005" (50.8-50.93 mm) diameter to accommodate the new sealing rings. Early units may be updated by using all three new parts as required. The 10-04-000-001 and 10-05-000-001 units are the forward and reverse portion of the V-Drive units.

<u>Trans. Assy.</u>	<u>Old Case</u>	<u>New Case</u>	<u>Old Shaft</u>	<u>New Shaft</u>	<u>Uses Thrust Washer</u>
10-04-000-001	10-04-565-003	10-04-565-005	71-1A2A or 10-17-659-002	10-17-695-020	Yes
10-05-000-001	10-05-565-002	10-05-565-012	72-1A2A or 10-18-659-002	10-18-659-014	Yes
10-17-000-001	71B-A1A	10-17-065-004	71-1A2	10-17-659-012	—
10-17-000-002	71B-A1A	10-17-065-004	71-1A2	10-17-659-012	—
10-17-000-003	71C-A1	10-17-065-006	71-1A2	10-17-659-012	—
10-17-000-004	71C-A1	10-17-065-006	71-1A2	10-17-659-012	—
10-17-000-005	71-A1K	10-17-565-002	10-17-659-002	10-17-659-020	Yes
10-17-000-006	71-A1K	10-17-565-002	10-17-659-002	10-17-659-020	Yes
10-17-000-007	71-A1K	10-17-565-002	71-1A2C	10-17-659-018	—
10-17-000-008	71-A1K	10-17-565-002	71-1A2C	10-17-659-018	—
10-17-000-009	71-A1K	10-17-565-002	10-17-659-004	10-17-659-016	Yes
10-17-000-010	71-A1K	10-17-565-002	10-17-659-004	10-17-659-016	Yes
10-17-000-011	71-A1K	10-17-565-002	71-1A2C	10-17-659-018	—
10-17-000-012	71-A1K	10-17-565-002	71-1A2C	10-17-659-018	—
10-17-000-013	71-A1K	10-17-565-002	71-1A2C	10-17-659-018	—
10-17-000-014	71-A1K	10-17-565-002	71-1A2C	10-17-659-018	—
10-17-000-015	71-A1K	10-17-565-002	71-1A2A	10-17-659-020	Yes
10-17-000-016	71-A1K	10-17-565-002	71-1A2A	10-17-659-020	Yes
10-18-000-001	72-A1J	10-18-565-001	72-1A2	10-18-659-006	—
10-18-000-002	72-A1J	10-18-565-001	72-1A2	10-18-659-006	—
10-18-000-003	72-A1K	10-18-565-002	10-18-659-002	10-18-659-014	Yes
10-18-000-004	72-A1K	10-18-565-002	10-18-659-002	10-18-659-014	Yes
10-18-000-005	72-A1K	10-18-565-002	72-1A2C	10-18-659-012	—
10-18-000-006	72-A1K	10-18-565-002	72-1A2C	10-18-659-012	—
10-18-000-007	72-A1K	10-18-565-002	10-18-659-004	10-18-659-010	Yes
10-18-000-008	72-A1K	10-18-565-002	10-18-659-004	10-18-659-010	Yes
10-18-000-009	72-A1K	10-18-565-002	72-1A2C	10-18-659-012	—
10-18-000-010	72-A1K	10-18-565-002	72-1A2C	10-18-659-012	—
10-18-000-011	72-A1K	10-18-565-002	72-1A2C	10-18-659-012	—
10-18-000-012	72-A1K	10-18-565-002	72-1A2C	10-18-659-012	—
10-18-000-013	72-A1K	10-18-565-002	72-1A2A	10-18-659-014	Yes
10-18-000-014	72-A1K	10-18-565-002	72-1A2A	10-18-659-014	Yes
10-18-000-015*	72-A1K	10-18-565-002	72-1A2A	10-18-659-008	—
10-18-000-016*	72-A1K	10-18-565-002	72-1A2A	10-18-659-008	—

* Inactive Lists




.010 MAX. R.
.005 MAX. R.
CIR. THICK. .073 MAX. EFFECTIVE WITH GAGE
1.248 DIA.
-TOOTH FORM SHALL BE A TRUE INVOLUTE OUTSIDE THIS DIA.




SPINE A
4 X SIZE
NO. OF TEETH 26
DIAMETRAL PITCH 20-40
DIAM. PRESS. ANGLE 30°
BASE CIRCLE DIA. 1.1258
ADDENDUM .0325
DEDENDUM .0365
FULL DEPTH .04975
FULL CUMULATIVE ERROR IN SPACING, TEETH TO MEASURE 1.4436 (MIN) OVER .096 DIA PINS. 1.4403 (MIN)


SECTION B-B




ALL UNITS ARE ADAPTABLE TO EITHER
RIGHT HAND ROTATION SHOWN.
RIGHT HAND ROTATION SHOWN.




MODEL 70 & 71




MODEL 70B & 71B




7-14 UNC-28 THDS
2 HOLES
OIL FROM COOLER
3-18 DRYSEAL NPSF TAP



ALL LINES & OIL PASSAGES
TO AND FROM OIL COOLER
MUST BE 1/32 DIA. OR
LARGER




MODEL 70C & 71C




3-18 DRYSEAL NPSF TAP
OIL LINE TO COOLER
3-18 DRYSEAL NPSF TAP

17-14 UNC-28 THDS-2 DEEP
MOUNTING HOLES
(PROVIDED BY CUSTOMER)




WHEN ORDERING REPLACEMENT PARTS
USE INDEX NUMBERS ON THIS DRAWING
TO IDENTIFY PART NUMBERS IN PARTS
LIST ON PAGE 15. INDEX LETTERS
REFER TO REPLACEMENT ASSEMBLIES.

Fig. 2 Cross Section of Model ASI-70C Transmission




WHEN REPLACEMENT PARTS
 USE INDEX NUMBERS ON THIS DRAWING
 TO IDENTIFY PART NUMBERS IN PARTS
 LIST ON PAGE 17. INDEX LETTERS
 REFER TO REPLACEMENT ASSEMBLIES.


Fig. 2 Cross Section of Model ASI-71C Transmission




WHEN ORDERING REPLACEMENT PARTS
USE INDEX NUMBERS ON THIS DRAWING
TO IDENTIFY PART NUMBERS IN PARTS
LIST ON PAGE 18. INDEX LETTERS
REFER TO REPLACEMENT ASSEMBLIES.




WHEN ORDERING REPLACEMENT PARTS
USE INDEX NUMBERS ON THIS DRAWING
TO IDENTIFY PART NUMBERS IN PARTS
LIST ON PAGE 18. INDEX LETTERS
REFER TO REPLACEMENT ASSEMBLIES.



WHEN ORDERING REPLACEMENT PARTS
USE INDEX NUMBERS ON THIS DRAWING
TO IDENTIFY PART NUMBERS IN PARTS
LIST ON PAGE 18. INDEX LETTERS
REFER TO REPLACEMENT ASSEMBLIES.



WHEN ORDERING REPLACEMENT PARTS
USE INDEX NUMBERS ON THIS DRAWING
TO IDENTIFY PART NUMBERS IN PARTS
LIST ON PAGE 18. INDEX LETTERS
REFER TO REPLACEMENT ASSEMBLIES.



10-18-000-001

PARTS LIST FOR MARINE UNITS WITH DIRECT DRIVE

INDEX NO.	W.G. PART NO.	DESCRIPTION	NO. REQ.	INDEX NO.	W.G. PART NO.	DESCRIPTION	NO. REQ.
1	4775L	Main shaft nut	1	71	5L-67	Clutch pressure plate	1
2	4547AY	Coupling (10-18)	1	73	71-97	Pressure plate pring	1
	4547BA	Coupling (10-17)	1	74	71-140	Oil baffle (10-18)	1
3	71C-110	Oil seal	1		71B-140	Oil baffle (10-17)	1
4	72-7	Bearing retainer (10-18)	1	75	12-A66	Clutch inner plate (10-18) *NOTE 4	1
	71-7	Bearing retainer (10-17)	1			Clutch inner plate (10-17) *NOTE 4	1
5	B309AGS	Annular bearing (10-18)	1	76	3-176	Clutch palte (steel)(10-18)	1
	B308AGS	Annular bearing (10-17)	1			Clutch palte (steel)(10-17)	1
6	72-147	Bearing retainer gasket (10-18)	1	77	5C-175A	Clutch pressure plate	1
	71-147	Bearing retainer gasket (10-17)	1	78	4755	Clutch spring snap ring	1
7	4737Q	7/16-14 x 1-1/8 Hex head bolt (10-18)	6	79	3-37	Clutch spring	1
	0000179859	7/16-14 x 1-1/8 Hex head bolt (10-17)	6	80	5C-33	Clutch spring bearing ring	1
8	X2979DR	7/16 Lockwasher (10-18)	6	81	5L-36	Clutch ring	1
	0000103322	7/16 Lockwasher (10-17)	6	82	71-45	Forward clutch piston	1
25	10-00-140-007	Neutral switch	1	83	5M-122	Sealing ring ("O" ring)	1
26	10-16-039-001	Valve cover	1	84	72-70	Forward clutch cylinder (10-18)	1
27	71-103	Switch cam	1		71-70	Forward clutch cylinder (10-17)	1
28	0000179796	1/4-20 Hex head bolt	3	85	71-15B	Thrust washer	1
29	0000103319	Lockwasher	3	86	B108A	Annular bearing (10-18)	1
31	0000179791	1/4-20 x 1/2 Hex head bolt	3		B107A	Annular bearing (10-17)	1
33	71-4	Valve cover	1	87	4559A	Snap ring (10-18)	1
34	71-14	Valve cover gasket	1		4734	Snap ring (10-17)	1
35	4821	Snap ring	1	88	4766B	Snap ring (10-18)	1
N.I.	71-A244A	Valve & spring assembly *NOTE 1	1		R6A-7-1/2	Snap ring (10-17)	1
	10-04-739-001	Valve & spring assembly *NOTE 1	1	89	4822	Ring gear snpa ring	1
36	71-246	Valve spring retainer	1	90	10-17-666-001	Reverse clutch plate assembly (10-18)	1
37	72N-242	Spring (white) *NOTE 1	1			Reverse clutch plate assembly (10-17)	1
	71-242	Spring (black) *NOTE 1	1	91	72-176	Outer clutch plate (10-18)	1
38	71-243	Pressure regulator valve	1	92	71-71	Reverse clutch pressure plate	1
39	71-244A	Forward & reverse gear trans. valve	1	93	71-35	Reverse clutch piston	1
40	4804H	"O" ring	1	94	4805A	Sealing ring	1
41	10-00-191-002	3/8-18 Plastic plug	1	95	4840D	Needle bearing	1
42	A4740G	Breather assembly	1	96	4804G	Sealing ring	1
43	444866	3/8-18 Pipe plug	1	97	71-144B	Case & adapter gasket	1
44	444687	1/8-27 Pipe plug	1	98	444858	1/4 Pipe plug	1
45	10-04-034-002	Dipstick tube *NOTE 2	1	99	71C-A8	Forward & reverse adapter	1
45A	10-13-559-001	Dipstick assembly *NOTE 2	1	100	4911	3/8-16 x 1-1/4 Cap screw	1
46	71-42	Poppet spring	1	N.I.	71C-A60	Pump assembly (includes 101, 102, 104, & 105)	1
47	453632	5/16 Steel ball	1	101	Not serviced	Pump drive gear (order assembly)	1
48	71-79B	Forward & reverse shift lever	1	102	Not serviced	Pump driven gear (order assembly)	1
49	115729	5/16-24 Hex nut	1	103	3-61	Pump gasket	1
50	108579	5/16 Lockwasher	1	104	Not serviced	Pump housing (order assembly)	1
51	103340	Control lever washer	1	105	10-00-044-014	Oil seal assembly	1
52	10-00-191-002	3/8-18 Plastic plug	1	106	10-00-183-021	5/16-18 x 1-3/8 Hex head bolt	1
53	4885B	Bushing	1	N.I.	71C-60	Pump assembly	1
54	71C-84	Oil return tube	1	N.I.	Kit A4867VV	2 Presized case bushings	1
55	71C-A98A	Oil strainer assembly (10-18)	1				
	71C-A98	Oil strainer assembly (10-17)	1				
56	71B-A1A	Case with bushing (10-17) not available	1				
		*NOTE 3	1				
56	72-A1J	Case with bushing (10-18) not available	1				
		*NOTE 3	1				
56	10-17-565-012	Case without bushing (10-17) *NOTE 3	1				
56	10-18-565-006	Case without bushing (10-18) *NOTE 3	1				
57	R6-177	Dowel pin (10-18)	3				
	71-87A	Dowel pin (10-17)	3				
58	4806B	Sealing ring	4				
59	72-1A2	Pinion cage & output shaft (10-18) *NOTE 3	1				
	71-1A2	Pinion cage & output shaft (10-18) *NOTE 3	1				
	10-17-659-012	Pinion cage & output shaft (10-17) *NOTE 3	1				
	10-18-659-006	Pinion cage & output shaft (10-18) *NOTE 3	1				
60	Kit A4867DD	2 Presized bushings	1				
61	Kit A4867DD	2 Presized bushing	1				
62	71-17	Thrust washer	1				
63	0000124553	Woodruff key (10-18)	1				
	000218211	Woodruff key (10-17)	1				
64	72C-2A16	Drive gear & plug assembly (10-18)	1				
	71C-3A16	Drive gear & plug assembly (10-17)	1				
65	4873	Woodruff key	1				
66	72-40	Forward clutch hub (10-18)	1				
	71-40	Forward clutch hub (10-17)	1				
67	4495	Snap ring	1				
68	4806J	Sealing ring	2				
69	72-6	Ring gear (10-18)	1				
	71-6	Ring gear (10-17)	1				
70	4768	Snap ring selective	1-2				
	4768A	(10-18 only)	1				
	4768B		1				
	10-00-139-019		1				

N.I. - NOT ILLUSTRATED

*NOTE 1 - See page 23

*NOTE 2 - See page 62

*NOTE 3 - See page 63

*NOTE 4 - See page 64





Fig. 11 Parts Display for Forward & Reverse ASI-70C Transmission

AS1-70C PARTS LIST

INDEX NO.	W.G. PART NO.	DESCRIPTION	NO. REQ.	INDEX NO.	W.G. PART NO.	DESCRIPTION	NO. REQ.
1	0000179822	5/16-18 x 1-1/2 Hex Head Bolt	4	N.I.	10-04-559-001	Dipstick Assembly-New Type	1
N.I.	10-00-183-021	5/16-18 x 1-3/8 Hex Head Bolt	4	N.I.	10-04-034-002	Dipstick Tube	1
A	71C-A60	Front Pump Assembly	1	57	0000145366	Drive Screw	2
2	71C-62A	Oil Seal Assembly	1	58	70B-A1A	Transmission Case & Bushing Assembly	1
3	N.S.S.	Front Pump Housing	1	59	Kit A4867VV	Case Bushings (Two Presized Bushing)	1
4	N.S.S.	Front Pump Driven Gear	1	60	71B-140	Baffle	1
5	N.S.S.	Front Pump Drive Gear	1	61	71C-A98	Oil Strainer Assembly	1
6	3-61	Front Pump Gasket	1	62	71C-84	Oil Return Tube	1
7	4911	Capscrew - 12 Point Head	4	63	4885B	Reducing Pipe Bushing	1
8	4840D	Needle Bearing	1	64	0000444866	3/8-18 Dryseal Plug	3
9	71C-A8	Forward & Reverse Adapter	1	E	71-A244A	Valve & Spring Assembly	1
10	0000444691	1/4-27 Dryseal Plug	1	65	4821	Snap Ring	1
11	71-35	Reverse Clutch Piston	1	66	71-246	Valve Spring Retainer	1
12	4805A	Sealing Ring	1	67	71-242	Valve Spring	1
13	4804G	"O" Ring	1	68	71-243	Pressure Regulator Valve	1
14	71-144B	Case & Adapter Gasket	1	69	71-244A	Forward & Reverse Gear Trans. Valve	1
15	71-71	Reverse Clutch Pressure Plate	1	70	4804H	"O" Ring	1
N.I.	71-87	Dowel Pin (Used With Fiber Plate)	3	71	71-14	Valve Cover Gasket	1
16	71-87A	Dowel Pin (Used With Metalic Plate)	3	72	71-4	Valve Cover	1
17	71-97	Pressure Plate Spring	12	73	0000103319	1/4 Lockwasher	3
18	71-86	Reverse Clutch Plate - Fiber	1	74	0000179793	1/4-20 x 5/8 Hex Head Bolt	3
N.I.	72-A66B	Reverse Clutch Plate - Metalic	1	75	71-42	Poppet Spring	1
19	71-158	Thrust Washer	1	76	0000453632	5/16 Steel Ball	1
20	B107A	Ball Bearing	1	77	71-79B	Forward & Reverse Shift Lever	1
21	R6A-7½	Snap Ring	1	78	0000103340	Control Lever Washer	1
22	4734	Snap Ring	1	79	0000108579	5/16 Lockwasher	1
23	5C-33	Clutch Spring Bearing Ring	1	80	0000115729	5/16-24 Hex Nut	1
24	71-45	Forward Clutch Piston	1	81	A4740G	Breather	1
25	5L-36	Sealing Ring	1	82	0000444687	1/8-27 Dryseal Plug	1
26	5M-122	"O" Ring	1	N.I.	A4867AH	Clutch Pack Kit	
27	3-37	Clutch Spring	1	N.I.	A4867AQ	Forward Clutch Cylinder Kit	
28	5L-67	Clutch Pressure Plate	1	N.I.	A4867HA	Gasket & Seal Kit	
29	5C-A66A	Clutch Inner Plate Assembly	3	N.I.	A4867WW	Small Parts Kit	
30	3-176	Clutch Outer Plate	2				
31	5C-175A	Clutch Pressure Plate	1				
32	4822	Ring Gear Snap Ring	1				
33	4755	Clutch Spring Snap Ring	1				
34	70-6	Ring Gear	1				
35	71-70	Forward Clutch Cylinder	1				
36	4495	Snap Ring	1				
37	71-40	Forward Clutch Hub	1				
38	71C-3A16	Drive Gear & Plug Assembly	1				
39	N.S.S.	3/8 Taper Plug	1				
40	71-17	Thrust Washer	1				
41	4873	Key No. 9 - No Rock	1				
42	4806J	Sealing Ring	2				
43	0000218211	Woodruff Key	1				
44	0000179859	7/16-14 x 1-1/8 Hex Head Bolt	6				
45	0000103322	7/16 Lockwasher	6				
46	71C-110	Oil Seal	1				
47	70-7	Bearing Retainer	1				
48	71-147	Bearing Retainer Gasket	1				
49	4775L	Main Shaft Nut	1				
50	4547BA	Coupling	1				
51	B208AGS	Annular Bearing	1				
52	71-1A2	Pinion Cage & Output Shaft Assembly	1				
53							
54	Kit A4867DD	Main Drive Gear Bushing - Two Presized Bushing in Kit					
55	4636EX	Name Plate	1				
56	71-A195	Dipstick Assembly-Screw-in Type	1				

N.I. - NOT ILLUSTRATED

N.S.S. - NOT SERVICED SEPARATELY



AS1-71C PARTS LIST

INDEX NO.	W.G. PART NO.	DESCRIPTION	NO. REQ.	INDEX NO.	W.G. PART NO.	DESCRIPTION	NO. REQ.
1	0000179822	5/16-18 x 1-1/2 Hex Head Bolt	4	N.I.	10-04-559-001	Dipstick Assembly-New Type	1
N.I.	10-00-183-021	5/16-18 x 1-3/8 Hex Head Bolt	4	N.I.	10-04-034-002	Dipstick Tube	1
A	71C-A60	Front Pump Assembly	1	57	0000145366	Drive Screw	2
2	71C-62A	Oil Seal Assembly	1	58	71B-A1A	Transmission Case & Bushing Assembly	1
3	N.S.S.	Front Pump Housing	1	59	Kit A4867VV	Case Bushings (Two Presized Bushing)	1
4	N.S.S.	Front Pump Driven Gear	1	60	71B-140	Baffle	1
5	N.S.S.	Front Pump Drive Gear	1	61	71C-A98	Oil Strainer Assembly	1
6	3-61	Front Pump Gasket	1	62	71C-84	Oil Return Tube	1
7	4911	Capscrew - 12 Point Head	4	63	4885B	Reducing Pipe Bushing	1
8	4840D	Needle Bearing	1	64	0000444866	3/8-18 Dryseal Plug	1
9	71C-A8	Forward & Reverse Adapter	1	E	71-A244A	Valve & Spring Assembly	1
10	0000444691	1/4-27 Dryseal Plug	1	65	4821	Snap Ring	1
11	71-35	Reverse Clutch Piston	1	66	71-246	Valve Spring Retainer	1
12	4805A	Sealing Ring	1	67	71-242	Valve Spring	1
13	4804G	"O" Ring	1	68	71-243	Pressure Regulator Valve	1
14	71-144B	Case & Adapter Gasket	1	69	71-244A	Forward & Reverse Gear Trans. Valve	1
15	71-71	Reverse Clutch Pressure Plate	1	70	4804H	"O" Ring	1
N.I.	71-87	Dowel Pin (Used With Fiber Plate)	3	71	71-14	Valve Cover Gasket	1
16	71-87A	Dowel Pin (Used With Metallic Plate)	3	72	71-4	Valve Cover	1
17	71-97	Pressure Plate Spring	12	73	0000103319	1/4 Lockwasher	3
18	71-86	Reverse Clutch Plate - Fiber	1	74	0000179793	1/4-20 x 5/8 Hex Head Bolt	3
N.I.	72-A66B	Reverse Clutch Plate - Metallic	1	75	71-42	Poppet Spring	1
19	71-15B	Thrust Washer	1	76	0000453632	5/16 Steel Ball	1
20	B107A	Ball Bearing	1	77	71-79B	Forward & Reverse Shift Lever	1
21	R6A-7 1/2	Snap Ring	1	78	0000103340	Control Lever Washer	1
22	4734	Snap Ring	1	79	0000108579	5/16 Lockwasher	1
23	5C-33	Clutch Spring Bearing Ring	1	80	0000115729	5/16-24 Hex Nut	1
24	71-45	Forward Clutch Piston	1	81	A4740G	Breather	1
25	5L-36	Sealing Ring	1	82	0000444687	1/8-27 Dryseal Plug	1
26	5M-122	"O" Ring	1	N.I.	A4867AE	Clutch Pack Kit	
27	3-37	Clutch Spring	1	N.I.	A4867AQ	Forward Clutch Cylinder Kit	
28	5L-67	Clutch Pressure Plate	1	N.I.	A4867HA	Gasket & Seal Kit	
29	5C-A66A	Clutch Inner Plate Assembly	5	N.I.	A4867WW	Small Parts Kit	
30	3-176	Clutch Outer Plate	4				
31	5C-175A	Clutch Pressure Plate	1				
32	4822	Ring Gear Snap Ring	1				
33	4755	Clutch Spring Snap Ring	1				
34	71-6	Ring Gear	1				
35	71-70	Forward Clutch Cylinder	1				
36	4495	Snap Ring	1				
37	71-40	Forward Clutch Hub	1				
38	71C-3A16	Drive Gear & Plug Assembly	1				
39	N.S.S.	3/8 Taper Plug	1				
40	71-17	Thrust Washer	1				
41	4873	Key No. 9 - No Rock	1				
42	4806J	Sealing Ring	2				
43	0000218211	Woodruff Key	1				
44	0000179859	7/16-14 x 1-1/8 Hex Head Bolt	6				
45	0000103322	7/16 Lockwasher	6				
46	71C-110	Oil Seal	1				
47	71-7	Bearing Retainer	1				
48	71-147	Bearing Retainer Gasket	1				
49	4775L	Main Shaft Nut	1				
50	4547BA	Coupling	1				
51	B308AGS	Annular Bearing	1				
52	71-1A2	Pinion Cage & Output Shaft Assembly	1				
53	Kit A4867DD	Main Drive Gear Bushing Two Presized Bushing in Kit					
54	4636FD	Name Plate	1				
55	71-A195	Dipstick Assembly-Screw-in Type	1				
56							

N.I. - NOT ILLUSTRATED

N.S.S. - NOT SERVICED SEPARATELY




Fig. 13 Parts Display for Forward & Reverse ASI-70B & ASI-71B Transmissions. Only Those Parts Different from the ASI-70C & ASI-71C Assembly Are Illustrated.




Fig. 14 Parts Display for Forward & Reverse ASI-70 & ASI-71 Transmissions. Only Those Parts Different from the ASI-70C & ASI-71C Assembly Are Illustrated.


ASI-71B & ASI-70B PARTS LIST

INDEX NO.	PART NO.	PART NAME	NO. REQ'D
1	179825	5/16-18x1-7/8 HEX HEAD BOLT	4
A	71-A60	FRONT PUMP ASSEMBLY	1
INDEX PARTS 2,3,4,5,84, & 85 MUST BE ORDERED AS ABOVE ASSEMBLY. SEAL (INDEX NO. 2) IS AVAILABLE SEPARATELY FOR REPLACEMENT, OR IN SMALL PARTS KIT (A4867M). INDEX PARTS 84 & 85 MAY BE OBTAINED SEPARATELY.			
2	71-62	OIL SEAL ASSEMBLY	1
3	71-60	PUMP HOUSING	1
9	71-8B	FORWARD & REVERSE ADAPTER	1
B	71-A16	DRIVE GEAR & PLUG ASSEMBLY	1
INDEX PARTS 38 & 39 MUST BE ORDERED AS ABOVE ASSEMBLY.			
38	71-16	DRIVE GEAR	1
41	431787	WOODRUFF KEY # 61	1
55	4636EK	NAME PLATE (ASI-70B ONLY)	1
	4636EL	NAME PLATE (ASI-71B ONLY)	1
56	3-2A195	OIL FILLER CAP & DIPSTICK ASSEMBLY	1
81	AJ2-87	BREATHING ASSEMBLY	1
83	3-196	OIL FILLER TUBE	1
84	71-3	PUMP BACKING PLATE	1
85	110533	#10-24x3/4 FLAT HEAD MACHINE SCREW	1

NOTE: WHEN ORDERING PARTS FOR ASI-70B, ASI-71B, ASI-70 & ASI-71 TRANSMISSIONS, USE THE APPROPRIATE ASI-70C or ASI-71C PARTS LIST TO IDENTIFY THOSE PARTS WHOSE INDEX NUMBERS ARE NOT LISTED IN THE ABOVE PARTS LIST. THE ABOVE ASI-70B, ASI-71B, ASI-70 & ASI-71 PARTS LIST SHOW ONLY THOSE PARTS WHICH DIFFER FROM THOSE IN ASI-70C & ASI-71C.

ASI-71 & ASI-70 PARTS LIST

INDEX NO.	PART NO.	PART NAME	NO. REQ'D
1	179825	5/16-18x1-7/8 HEX HEAD BOLT	4
A	71-A60	FRONT PUMP ASSEMBLY	1
INDEX PARTS 2,3,4,5,84, & 85 MUST BE ORDERED AS ABOVE ASSEMBLY. SEAL (INDEX NO. 2) IS AVAILABLE SEPARATELY FOR REPLACEMENT, OR IN SMALL PARTS KIT (A4867M). INDEX PARTS 84 & 85 MAY BE OBTAINED SEPARATELY.			
2	71-62	OIL SEAL ASSEMBLY	1
3	71-60	PUMP HOUSING	1
9	71-8B	FORWARD & REVERSE ADAPTER	1
B	71-A16	DRIVE GEAR & PLUG ASSEMBLY	1
INDEX PARTS 38 & 39 MUST BE ORDERED AS ABOVE ASSEMBLY.			
38	71-16	DRIVE GEAR	1
41	431787	WOODRUFF KEY # 61	1
55	4636DF	NAME PLATE (ASI-70 ONLY)	1
	4636DL	NAME PLATE (ASI-71 ONLY)	1
56	3-2A195	OIL FILLER CAP & DIPSTICK ASSEMBLY	1
D	70-A1C	TRANSMISSION CASE & BUSHING ASSEMBLY (ASI-70 ONLY)	1
	71-A1G	TRANSMISSION CASE & BUSHING ASSEMBLY (ASI-71 ONLY)	1
INDEX PARTS 58 & 59 MUST BE ORDERED AS ABOVE ASSEMBLY. BUSHINGS (INDEX NO. 59) ARE AVAILABLE FOR REPLACEMENT IN SERVICE KIT (A4867VV).			
58	70-1C	FORWARD & REVERSE TRANSMISSION CASE (ASI-70 ONLY)	1
	71-1G	FORWARD & REVERSE TRANSMISSION CASE (ASI-71 ONLY)	1
60	71-140	BAFFLE	1
61	71-A98C	OIL STRAINER	1
63	4885	BUSHING	1
81	AJ2-87	BREATHING ASSEMBLY	1
83	3-196	OIL FILLER TUBE	1
84	71-3	PUMP BACKING PLATE	1
85	110533	#10-24x3/4 FLAT HEAD MACHINE SCREW	1
86	120428	ANNULAR GASKET	1



DESCRIPTION




Fig. 16 External Views ASI-70C or ASI-71C




Fig. 16A External Views ASI-70 or ASI-71

This manual is prepared primarily for the Model 70C & 71C direct drive transmissions. However, all additional supplementary descriptions and illustrations are included to allow it to be used for the Model 70B, 71B, 70 and 71 transmissions.

The material in this manual is also used in conjunction with the proper reduction gear manuals for servicing all 70, 70R, 70C, 70CR, 71, 71R, 71C and 71CR reduction gear transmissions.

The following list identifies the important features of the various model transmissions in (Figs. 16 and 16A):

- | | |
|--|--------------------------------|
| A. Oil filler cap & dipstick assembly | G. Drive Gear |
| B. Oil outlet to cooler | H. Output shaft flange |
| C. Oil inlet from cooler | I. Shift lever |
| D. Oil drain plug | J. Valve cover |
| E. Oil pump | K. Breather |
| F. Mounting pads & mounting bolt holes | L. Main line pressure tap |
| | M. Reverse clutch pressure tap |

The transmission consists of a planetary gear set, a forward clutch, a reverse clutch, an oil pump, and a pressure regulator and rotary control valve. All of these are contained in a cast iron housing along with necessary shafts and connectors, to provide forward, reverse and neutral operation. A direct drive ratio is used for all forward operation. In reverse, the speed of the output shaft is equal to input speed,

The following are the identification markings for the Warner Gear "VELVET DRIVE" Marine Transmissions.

"A" MODEL	HAND OF ROTATION	"A" MODEL	HAND OF ROTATION	"B" RATIO	"C" COLOR
*AS1-71C	CLOCKWISE	*AS1-71CR	COUNTER CLOCKWISE	1:1	RED
AS1-71B	CLOCKWISE	AS1-71BR	COUNTER CLOCKWISE	1:1	RED
AS1-71	CLOCKWISE	AS1-71R	COUNTER CLOCKWISE	1:1	RED
*AS1-70C	CLOCKWISE	*AS1-70CR	COUNTER CLOCKWISE	1:1	BLUE
AS1-70B	CLOCKWISE	AS1-70BR	COUNTER CLOCKWISE	1:1	BLUE
AS1-70	CLOCKWISE	AS1-70R	COUNTER CLOCKWISE	1:1	BLUE

The hand of rotation referred to above is when viewed from stern of boat looking forward.
*TRANSMISSION ASSEMBLIES PRESENTLY IN PRODUCTION.

but in the opposite direction. Helical gearing is used to provide quieter operation than can be obtained with spur gear gearing.


The transmission is fast shifting to give the boat operator complete control of the vessel. Shifting is accomplished by the fore and aft movement of the shift lever, (Fig. 16). This movement rotates the control valve and directs oil under controlled pressure to the required channels.

Oil pressure is provided by the crescent type pump, the drive gear of which is keyed to the drive shaft and operates at transmission input speed to provide screened oil to the pressure regulator.

From the regulator valve the oil is directed through the proper circuits to the bushings and anti-friction bearings requiring lubrication. A flow of lubricant is present at the required parts whenever the front pump is turning and it should be noted that supply is positive in forward, neutral and reverse conditions.

The unit has seals to prevent escape of oil.

Both the input and output shafts are coaxial, with the input shaft splined for the installation of a drive damper, and the output shaft provided with a flange for connecting to the propeller shaft.



INSTALLATION PRECAUTIONS

TRANSMISSION OIL COOLER

The oil cooler must be properly connected to the transmission before the engine is cranked or started. Failure to properly connect the oil cooler will result in the blowing out of the forward clutch piston due to over pressurization. NO WARRANTY claims due to this type failure will be allowed as this is the responsibility of the Boat Builder, Engine Manufacturer or Conversion Engine Manufacturer.

A cooler of sufficient size shall be used to assure that the maximum oil temperature of the transmission will not exceed 190°F. Failure to provide proper cooling may result in damage to the transmission from insufficient oil flows and pressures if the transmission is operated at temperatures above the maximum recommended.

The proper oil cooler inlet and outlet connections are shown in (Figures 16 & 16A).

CONTROL LEVER POSITION

The position of the control lever on transmission when in forward should be shifted to the point where it covers the letter "F" on the case casting, and is located in its proper position by the poppet ball. The WARRANTY is cancelled if the shift lever poppet spring and/or ball is permanently removed, or if the control lever is changed in any manner, or repositioned, or if linkage between remote control and transmission shift lever does not have sufficient travel in both directions. This does not apply to transmissions equipped with Warner Gear electrical shift control.

FRONT PUMP MOUNTING

Before mounting the transmission on the engine be sure that the pump is correctly installed. Orient the pump mounting bolt holes and arrows indicating direction of rotation to correspond with the direction of rotation required by the engine. If the pump is not installed for the proper rotation the pump will not produce oil pressure to operate the transmission when engine is started.

LUBRICATION RECOMMENDATIONS

PROCEDURE FOR FILLING TRANSMISSION WITH OIL

When filling the transmission, oil should be added until it reaches the full mark on the dipstick. The quantity of oil depends upon the angle of the installation, but information to serve as a guide on possible amount needed may be found in chart below. The unit should be turned over at engine idle speed for a short time in order to fill all circuits, including the cooler and cooler piping.

NOTE: Be sure the cooler is properly installed and the transmission contains oil before cranking or starting engine.

CHECKING OIL LEVEL

Check the oil level daily before starting the engine. Oil will sometimes drain back into the transmission from the cooler when improperly installed. It is important that oil level checks on new installations be made immediately after the engine has been shut off and before the oil has had a chance to drain back. If you have drain back, correct the installation.

CHANGING OIL

A seasonal oil change is recommended in pleasure boats. Work boats require more frequent changes. Change oil anytime the oil becomes contaminated, changes color, or becomes rancid smelling.

TRANSMISSION FLUID

Dexron®II, Type F, and other hydraulic transmission fluids which meet the Detroit Diesel Allison Type C3 specifications are recommended for use in all Velvet Drive® marine transmissions.

Lubricating oils which are recommended for use in diesel engines and also meet Detroit Allison Type C3 specifications may be used if the engine speed does not exceed 3000 RPM. SAE #30 is preferred. SAE #40 is acceptable if high operating temperatures are to be encountered. Multi-viscosity oils such as 10W-40 are not acceptable. The first choice is an oil which falls in the SAE-API service Class "CD." The second choice would be an oil which falls in the SAE-API service Class "CC."

The equivalent DOD mil specs are:

"CD" Mil-L-2104B

"CC" Mil-L-45199

The new C3 specifications were developed by Detroit Diesel Allison Division of General Motors to outline the requirements of an oil suitable for use in their heavy duty hydraulic automatic and powershift transmissions. The oil companies should be able to provide information as to the suitability of their product for use in a given application.

OIL CAPACITY

TRANSMISSION MODEL	TRANSMISSION OIL CAPACITY (QUARTS)	
	LEVEL	15° INCLINED
AS1-70C or CR	1.8	1.3
AS1-71C or CR	1.8	1.3

NOTE: OIL CAPACITY DOES NOT INCLUDE CAPACITY NEEDED FOR TRANSMISSION COOLER AND OIL LINES, WHICH MAY IN MANY CASES REQUIRE AN ADDITIONAL AMOUNT GREATER THAN IN ABOVE TABLE.

TRANSMISSION OPERATION




Fig. 17 ASI-71C Shift Lever Positions

FORWARD

Move the transmission shift lever to the extreme forward position where the spring-loaded ball enters the chamfered hole in the side of the shift lever and properly locates it in the "forward" position, (Fig. 17). With the shift lever so located, oil at regulated pressure flows from the control valve into porting in the transmission case, output shaft, drive gear, forward clutch cylinder, and into the forward clutch cavity. The resulting movement of the forward clutch piston and the lever action of the clutch spring forces the multiple discs of the forward clutch together and, with the aid of the forward clutch hub, locks the input shaft to the ring gear. This in turn prevents rotation of the planetary pinions about their own axes and thus locks the input shaft, ring gear and output shaft together, causing them to rotate as a solid concentric coupling. In this way, input shaft speed and direction of rotation are transmitted directly to the output shaft.

NEUTRAL

Move the transmission shift lever to the center position where the spring-loaded ball enters the chamfered hole in the side of the shift lever and properly locates it in the "neutral" position, (Fig. 17). With the shift lever so located, flow of pressurized oil to the clutches is blocked at the control valve. The clutches are also vented, by a different portion of the control valve, to the sump area inside the transmission case and thus free-running open clutches are insured.

REVERSE

Move the transmission shift lever to the extreme rearward position where the spring-loaded ball enters the chamfered hole in the side of the shift lever and properly locates it in the "reverse" position, (Fig. 17). With the shift lever so located, oil at regulated pressure flows from the control valve into porting in the transmission case, thence back to the adapter and into the reverse clutch cavity. The resulting movement of the reverse clutch piston and the reverse clutch pressure plate locks the reverse clutch plate to the transmission case. The stationary reverse clutch plate, through splined connectors, thus prevents rotation of the ring gear. With the ring gear held and the sun gear rotating at input speed, the pinions of the compound planetary gearset are free to rotate about their own axes and reverse the direction of rotation of the pinion carrier and output shaft.

FREEWHEELING

Under sail with the propeller turning, or at trolling speeds with one of two engines shut down, the design of the Velvet Drive gear maintains adequate cooling and lubrication.

OIL PRESSURES

Transmission line pressure should be between 110-150 PSI at engine speeds between 450 and 2000 RPM at normal operating temperatures of 150-165°F.

When operating the transmission at low temperatures or excessive speeds pressures of 200-250 PSI may be obtained.

A maximum transmission oil temperature of 190°F. is recommended.

See page 23 for pressure specifications on 10-17 units.

***NOTE #1**

Subject: Revised Pressure Specifications and Effective Serial Numbers for Changeover to Sealing Rings as Described in MB 24.

Effective serial numbers for the addition of sealing rings to In-Line units, models 10-17 and 10-18:

10-17-000-001	10440	10-18-000-001	2169
-002	5811	-002	2152
-003	101	-003	781
-004	241	-004	2023
-005	1624	-005	563
-006	3767	-006	2880
-007	838	-007	775
-008	3697	-008	2557
-009	351	-009	793
-010	4913	-010	829
-011	470	-011	421
-012	1904	-012	1282
-013	979	-013	101
-014	2708	-014	2784
-015	113		
-016	143		

These serial numbers are to be used in conjunction with MB 24. The regulator valve spring was also changed to provide additional cooler flow. The new regulator spring 72N-242 is white for identification. The new valve and spring assembly part number is 10-04-739-001. The old spring 71-242 or valve and spring assembly 71-A244A should be used when case bushings are used, and the new parts should be used when sealing rings are used in either the 10-17, 10-18, or any of the V-Drive assemblies. The spring was changed a short time after the V-Drive units were changed to the sealing rings; therefore there will be a few V-Drive units which will have the old spring used with sealing rings.

The pressure chart below should be used for checking pressure of all units having the new regulator spring.

Engine RPM	Neutral Line		Forward Clutch		Reverse Clutch	
	Min.	Max.	Min.	Max.	Min.	Max.
500	90	120	90	120	90	120
2000	—	—	100	125	100	125

DISASSEMBLY OF TRANSMISSION

NOTE: Tear down procedure should not begin until the transmission exterior and work area have been thoroughly cleaned.

OIL DRAINING PROCEDURE

1. Remove oil filler plug located below the shift lever on rear left side of transmission case.
2. If space permits, place container having approximately two (2) quart capacity under drain cap, located as shown in (Fig. 18). Unscrew the drain plug and cooler return tube assembly, reach into the opening with a suitable tool, and remove the strainer assembly, (Fig. 77). Allow oil to drain into pan.

DISASSEMBLY OF VALVE AND SPRING ASSEMBLY FROM TRANSMISSION

3. Remove three (3) hex head bolts, lockwashers, valve cover and valve cover gasket, as shown in (Fig. 74).
4. Remove shift lever and associated parts, (Fig. 75).
5. Tap with soft hammer on exposed threaded shaft, upon which shift lever was mounted, and pull valve

and spring assembly out of case from right side, (Fig. 73).

6. Place valve and spring assembly in a suitable holder, (Fig. 71). Depress the valve spring retainer and valve spring until the snap ring is free to be removed. The components of the valve and spring assembly can now be removed in the order shown in (Fig. 70).

NOTE: The control valve assembly can also be disassembled by using an arbor press with suitable tools as shown in (Fig. 72).

REMOVAL OF FRONT PUMP ASSEMBLY

7. Remove the four (4) front pump attaching bolts, (Fig. 69), place a protective covering over splines to prevent damage to seal lip, and lift pump assembly squarely up and over the protruding input shaft, (Fig. 67).
8. Remove pump drive gear, front pump gasket, and Woodruff key, (Fig. 66).

NOTE: Two different pump assemblies are used. One includes a backing plate which must be removed before the gears are exposed. For additional information and description see pages 40 and 48-51.

9. For the pump assembly with the backing plate, remove the one (1) flat head machine screw, (Fig. 96) and lift backing plate to expose gears.
10. Mark gears to identify for proper relocation of gear faces during reassembly, (Figs. 65 and 94). (Figs. 62 and 91) show views of the different front pump parts when completely disassembled.




Fig. 18 Draining Transmission Oil

DISASSEMBLY OF ADAPTER AND REVERSE CLUTCH PISTON

11. Remove the four (4) cap screws (12 point head), (Fig. 61). Lift the adapter and reverse clutch piston, (Fig. 60). If necessary, tap the adapter with a soft hammer to remove.

CAUTION: The reverse clutch pressure plate may stick momentarily to the reverse clutch piston. To avoid damage, prevent pressure plate from dropping.

12. Force compressed air into reverse clutch cavity while holding piston, as shown in (Fig. 19) and piston will pop up out of reverse clutch cavity.
13. Remove sealing rings as shown in (Figs. 57 and 58).

REMOVAL OF THRUST WASHER, REVERSE CLUTCH PRESSURE PLATE, PRESSURE PLATE SPRINGS AND DOWEL PINS

14. Thrust washer can now be lifted from position shown in (Fig. 56).
15. Remove clutch pressure plate as shown in (Fig. 55).
16. The twelve (12) pressure plate springs and the three (3) dowel pins can now be removed, (Fig. 54).

DISASSEMBLY OF DRIVE GEAR AND CLUTCH ASSEMBLY

17. Grasp the exposed front end of the input gear and lift straight up; drive gear and clutch assembly parts easily lift out of opening in front, (Fig. 53).
18. Remove thrust washer located between drive gear and planetary carrier, (Fig. 52).
19. Stand drive gear and clutch assembly in suitable fixture and remove internal & external snap rings at ball bearing from the drive gear and clutch cylinder, (Figs. 50 and 51). Do not permit drive gear to move forward after the above snap rings are removed.

20. While holding the ring gear, tap the front end of the drive gear with soft hammer. The drive gear and forward clutch hub assembly will pass through the ring gear and forward clutch assembly to come out of the rear end of the ring gear, (Fig. 47).

DISASSEMBLY OF FORWARD CLUTCH

21. Remove bearing from clutch cylinder by tapping with soft blunt tool.
22. Remove ring gear snap ring, (Fig. 43).
23. While holding ring gear, tap with soft blunt tool on exposed face of forward clutch cylinder inside of ring gear. Forward clutch cylinder will move forward to disassemble out of front of ring gear. After removing the clutch spring and the clutch spring snap ring, all parts of the forward clutch can be disassembled as shown in (Figs. 34, 35, 36, 37 & 38).
24. Piston can be removed from forward clutch cylinder to position in (Fig. 41) by applying compressed air to clutch cavity through one of three (3) holes in inside diameter of forward clutch cylinder, while other holes are blocked.




Fig. 19 Disassembling Reverse Clutch Piston in Adapter

25. Remove forward clutch sealing rings, as shown in (Figs. 39 & 40).

REMOVAL OF PINION CAGE AND OUTPUT SHAFT ASSEMBLY FROM TRANSMISSION CASE

26. Remove main shaft nut shown in (Fig. 33).
27. Using bearing puller, pull coupling from output shaft.
28. Remove six (6) hex head bolts and lockwashers, (Fig. 31).
29. Remove bearing retainer and gasket.

REMOVAL OF REAR BEARING

NOTE: The following paragraphs (30 & 31) describe alternate methods of removing the rear bearing. Either method is equally desirable.

30. Using bearing puller, grasp bearing by exposed groove in outside diameter and gently pull bearing from case, (Fig. 20).




Fig. 20 Removing Bearing from Case

31. Place transmission, with front face down, on arbor press. Using suitable tool, press down on exposed end of output shaft until shaft is free of bearing inside diameter. Protect pinion cage and output shaft from damage from fall during this operation.

REASSEMBLY PRECAUTIONS

The following list contains a number of assembly problems which it is felt requires special attention during the reassembly of the direct drive transmissions. The information below includes the locations in the manual where information and instructions are available on these important assembly features.

1. Installation of proper pinion cage and output shaft assembly in transmission cases without bushings, (Page 52, Paragraphs 18 & 19).
2. Selection of the proper clutch spring snap ring, (Page 31, Paragraph 23).
3. Selection of the proper ring gear snap ring, (Page 33, Paragraph 30).
4. Installation of adapter on transmission case should follow the procedures outlined, (Page 39, Paragraph 56), for tightening the capscrews. If bolts are not alternately tightened a small amount, damage can result to the needle bearing and its input shaft race.
5. Protection of pump seal during assembly of pump assembly over input drive gear, (Page 41, Paragraph 65).
6. Mounting pump to correspond to the engine rotation, (Page 42, Paragraph 67).
7. Check input shaft to insure that it rotates freely when turned by hand after transmission is assembled (Page 42, Paragraph 69).

INSPECTION AND GENERAL INSTRUCTIONS

1. Cleanliness is absolutely necessary during assembly to insure proper functioning of transmission. Transmission case passages should always have pipe plugs removed to allow for thorough cleaning. When available, use compressed air to dry parts before they are assembled. Do not wipe parts with rags to clean or dry them as lint from the cloth may cause erratic valve action.
2. Inspect all parts for damage or wear. Replace defective parts.
3. All gaskets, oil seals and rubber sealing rings should be replaced except in relatively new units. Judgement should then be exercised as to the need for replacing these parts.
4. Oil seals and bearings are best installed by using an arbor press, suitable fixtures, and tools to properly align parts being assembled. Hammering seals and bearings into position can severely damage parts.
5. Automatic transmission fluid type "A" suffix "A" should be used to lubricate parts as they are assembled. Petroleum jelly may be used on gaskets or other parts that must be held in position during assembly. All rubber parts will slide more freely if lubricated.
6. Tighten all bolts and screws evenly to the recommended torque, (See page 60).

ASSEMBLY OF TRANSMISSION

ASSEMBLING OIL SEAL IN BEARING RETAINER

1. Inspect rubber lip of seal for cracks, holes or brittle condition of rubber lip material.
2. Place front face of bearing retainer on arbor press table. Apply a suitable sealant to the outside diameter of seal before installing squarely

into bore of housing with seal lip positioned as shown in (Fig. 21). Caution should be observed to insure that too much sealant is not used.

3. Using arbor press and suitable tool, as shown in (Fig. 22), press the oil seal into the bearing retainer until the rear face of the oil seal is flush with the rear face of the bearing retainer.




Fig. 21 Installing Oil Seal




Fig. 22 Pressing Oil Seal in Retainer




Fig. 23 Installing Model 71B & 71C Baffle

INSTALLATION OF THE BAFFLE IN THE TRANSMISSION CASE

4. Insert the baffle inside the transmission case with the notched side toward the front and the curve of baffle toward the bottom of the transmission case, (Fig. 23).
5. Press down on the baffle and snap the rectangular slots at each end on to the cast bosses at each side of the case, (Fig. 24). These bosses will position and hold the baffle in its proper place.




Fig. 24 Model 70B & 70C Oil Baffle Properly Installed




Fig. 25 Pinion Cage and Output Shaft Assembly in Place on Arbor Press

INSTALLATION OF PINION CAGE AND OUTPUT SHAFT ASSEMBLY IN THE TRANSMISSION CASE

6. Place the pinion cage and output shaft assembly on a 5 inch diameter by 2-5/8 long assembly tool, which in turn is mounted on an arbor press, as indicated in (Fig. 25).

NOTE: If the transmission case does not have bronze bushings for the output shaft journal, use only the output shafts of the design with three oil grooves as shown in (Fig. 26). See page 52 (paragraphs 18 & 19), for further information.




Fig. 26 Late and Early Model Pinion Cage and Output Shafts




Fig. 27 Case Assembled over Pinion Cage and Output Shaft Assembly and Assembly Tool

7. Place the transmission case over the pinion cage and output shaft assembly so transmission case rests squarely on arbor press table which is supporting assembly tool (Fig. 27).
8. Inspect the bearing bore for possible dirt or burrs.
9. Inspect the rear bearing for scored or damaged balls and races and for loose or cracked ball retainer. Replace the bearing with a new part if damage is detected.
10. Inspect the bearing for presence of dirt. If dirt is present, wash bear-




Fig. 29 Rear Bearing Pressed in Place

- ing until clean and lubricate with automatic transmission fluid, type "A", suffix "A", before assembly.
11. With the groove on the outside diameter of the bearing located toward the rear of the transmission, as shown in (Fig. 28), place the bearing over the projecting output shaft and squarely in the bearing bore.
12. Using an assembly tool designed to press evenly on the bearing outer and inner races, press bearing down until seated against shaft or case shoulder, (Fig. 29).




Fig. 28 Rear Bearing Properly Positioned on Transmission Case



Fig. 30 Bearing Retainer Gasket in Place




Fig. 31 Assembling Bearing Retainer on Rear of Case

13. Place bearing retainer gasket on rear of transmission case as shown in (Fig. 30). Gasket may be coated with petroleum jelly for easier assembly.

14. Place bearing retainer in place on rear of case as shown in (Fig. 31). Install six (6) 7/16 lockwashers and six (6) 7/16-14 hex head bolts; tighten bolts to a torque of 42-50 pounds-feet.




Fig. 32 Pressing Rear Coupling in Place



Fig. 33 View of Completely Assembled Output Shaft

15. Inspect and lubricate the hub diameter of rear coupling which runs in contact with the rubber lip of oil seal. If this surface is scratched or burred, replace the part with a new piece to prevent seal-lip damage and subsequent oil leakage.

16. After lubricating the splined portion of coupling, assemble the splined coupling onto the externally splined portion of the output shaft. When the coupling has been aligned squarely on the output shaft and hand assembly has proceeded as far as possible, place a suitable tool on the coupling, (Fig. 32), and gently press the coupling with arbor press until contact with the bearing inner race is made.

17. Assemble main shaft nut in place on output shaft and tighten to prescribed torque of 100 to 200 pounds-feet. This should bring inner race of bearing solidly in contact with the shoulder on output shaft and eliminate any detectable end play in the coupling and output shaft combination, (Fig. 33).

ASSEMBLING DRIVE GEAR AND CLUTCH ASSEMBLY

37. With drive gear and clutch hub in assembly tool as shown in (Figs. 45 and 46), place ring gear and forward clutch assembly over drive gear as shown in (Fig. 47).

38. Lower ring gear and clutch assembly until internal teeth of clutch plates begin to engage teeth on forward clutch hub. Rotate ring gear to align teeth of plates with teeth on clutch hub. Do not force ring gear, as damage to teeth on plates will result. When ring gear and clutch are in correct position, rear end of ring gear should be against the assembly tool or "flush" with the rear thrust face of drive gear, as shown in (Fig. 48). Do not remove drive gear and clutch assembly from assembly tool or move drive gear forward until steps 39, 40 and 41 are completed. Any movement of the drive gear forward will result in the clutch plates becoming disengaged with clutch hub and sealing rings moving out of position.

39. Place aligned parts and assembly tool in place on arbor press. Place bearing over protruding drive gear and squarely into bore at front of forward clutch cylinder; press bearing down with arbor press until bearing is fully seated on shoulder and snap ring grooves in front of bearing are exposed (Fig. 49).




Fig. 48 Assembling Ring Gear and Clutch Assembly on Drive Gear



Fig. 47 Assembling Ring Gear and Clutch Assembly on Drive Gear




Fig. 49 Pressing Clutch Bearing in Place




Fig. 50 Installing Snap Ring

40. Install external snap ring on drive gear, (Fig. 50).

41. Install internal snap ring in clutch cylinder, (Fig. 51).




Fig. 51 Installing Snap Ring

INSTALLATION OF DRIVE GEAR AND CLUTCH ASSEMBLY, REVERSE CLUTCH PLATE, AND REVERSE CLUTCH PRESSURE PLATE IN TRANSMISSION CASE

42. Place the parts assembled in steps 1 through 17 inclusive, on a smooth, clean surface in the upright position indicated in (Fig. 52): In this position, the rear face of rear coupling will provide sufficient base to enable assembly to proceed.




Fig. 52 Installing Thrust Washer

43. Coat the drive gear thrust washer with petroleum jelly and assemble into pinion cage and output shaft assembly, as shown in (Fig. 52). Center the washer carefully over bore provided for rear of drive gear.

44. After lubricating the rear end of the drive gear and checking centered position of the thrust washer, install the drive gear and clutch assembly into the case and pinion cage and output shaft assembly, (Fig. 53). Care and proper centering must be exercised at this point to prevent damage to the bushings when the rear diameter of the drive gear enters the output shaft.

45. Install the twelve (12) pressure plate springs in the holes provided in the reverse clutch cavity, (Fig. 54). The holes should be free from dirt and all springs should be firmly seated.

46. Coat the three (3) dowel pins with petroleum jelly and assemble them in the three (3) grooves provided at the outside diameter of the reverse clutch cavity, (Fig. 54). Assembly is complete when the dowel pin is firmly seated on end and into the groove, as far as groove contour will permit.




Fig. 54 Installation of Twelve (12) Pressure Plate Springs and Three (3) Dowel Pins




Fig. 53 Installing Drive Gear and Clutch Assembly

47. Install reverse clutch plate over exposed splined teeth of ring gear. Clutch plate must be firmly and evenly seated on the case face forming the rear of the reverse clutch cavity, (Fig. 55).

48. Install the reverse clutch pressure plate with the twelve (12) holes in the downward position. Align the cast slot in the pressure plate with the large oil hole in the front face of the transmission case, (Fig. 55). Since the twelve (12) pressure plate springs are not evenly spaced, the slot and oil hole alignment are




Fig. 55 Installing Reverse Clutch Pressure Plate




Fig. 62 Front Pump Parts for Assembly 71C-A60

ASSEMBLY OF FRONT PUMP

57. Collect the parts shown in (Fig. 62) and check carefully for the following:

- (a) Scoring in gear pockets, crescent, and gear face.
- (b) Oil seal lip for brittle condition, cracks and cuts. Oil seal outside diameter for dents or scratches.
- (c) Gear teeth for burrs.




Fig. 63 Installing Pump Oil Seal

NOTE: Two different pump assemblies have been used on the Model 70C & 71C transmission. If the pump assembly on your transmission includes a backing plate see page 48 (paragraphs 5 through 10) for important information concerning its assembly and service.

The front pump assembly without the backing plate can only be used with the new (71C-A8) adapter (Fig. 61), the new key (4873), and the new version of the drive gear with the relocated pump keyway. For identification of the proper parts see (Fig. 90).




Fig. 64 Pressing Pump Oil Seal into Housing

58. Place pump housing squarely on arbor press table. Apply a suitable sealant to the outside diameter of seal before installing squarely into bore of housing with seal lip positioned as shown in (Fig. 63). Caution should be observed to insure that too much sealant is not used, that any excess is wiped away after the seal is installed, and that the sealant does not get on the sealing element.

59. Using an arbor press and suitable tool, press seal into housing until front face of seal is flush with front face of pump housing (Fig. 64).

60. After seal is assembled, lubricate the pump housing with the proper transmission oil and place as shown in (Fig. 65). Install lubricated driven pump gear with identification mark as shown in (Fig. 65).

MOUNTING FRONT PUMP ON TRANSMISSION

61. Place parts assembled in steps 1 through 56 inclusive as shown in (Fig. 61), after inspecting the adapter face for dirt and obstructions.
62. Lubricate and install front pump gasket, (Fig. 66).




Fig. 65 Installing Pump Driven Gear

63. Install Woodruff key, (Fig. 66).

NOTE: Check (Fig. 90) to determine that proper key and shaft are used.

64. Install the pump drive gear on the input shaft, with one of the Woodruff key slots in drive gear mating with the Woodruff key on the input shaft, (Fig. 66).

NOTE: The two pump gears should be assembled so that the same gear faces are matched with the machined face of the pump housing as found at disassembly. Marks should have been applied at disassembly to insure proper reassembly, (Page 24, paragraph 10).




Fig. 66 Installing Pump Drive Gear Key and Front Pump Gasket

65. Cover the splined portion of the input drive gear with a suitable tool to protect the rubber lip on the seal during the assembly of the remaining front pump parts, (Fig. 66).
66. With the pump driven gear properly installed in the front pump housing, assemble the housing and pump driven gear squarely over the protruding input shaft and assembly tool. A slight rotation of the pump housing and pump driven gear will allow engagement of pump gear teeth, (Fig. 67).




Fig. 67 Installing Pump over Seal Protector




Fig. 68 Orientation Markings for Present 71C-A60 Pump on the 71C-8 Adapter

67. Orient the pump mounting bolt holes and arrow indicating direction of rotation to correspond with the direction of rotation required by the engine, (Fig. 68). If not installed for the proper rotation the pump will not produce oil pressure to operate the transmission when engine is started.

NOTE: WITH THE EXCEPTION OF THE 2.10/1 REDUCTION GEAR THE ORIENTATION OF THE PUMP ON THE TRANSMISSION MAY BE CHANGED FOR INSTALLATION ON ENGINES WITH ROTATION OPPOSITE TO THAT FOR WHICH THE TRANSMISSION




Fig. 69 Mounting Front Pump to Adapter

WAS ORIGINALLY ASSEMBLED. THE HAND OF ROTATION OF THE PUMP ON A 2.10/1 TRANSMISSION SHOULD ALWAYS AGREE WITH ORIGINAL FACTORY INSTALLATION AND MUST NOT BE CHANGED.

68. With the pump assembled squarely against the adapter and pump gasket, and the seal assembly tool removed, install four (4) 5/16-18 hex head bolts, (Fig. 69). Tighten hex head bolts evenly to torque of 17-22 pounds-feet.
69. Check freedom of rotation of pump gears in pump housing by rotating the input shaft. If the pump will not rotate freely, disassemble the pump and check for foreign material




Fig. 70 Exploded View of Valve and Spring Assembly

in the pump. Any dirt particles on the adapter face will also tend to cock the pump when mounted on the adapter and cause it to seize.

ASSEMBLING VALVE AND SPRING ASSEMBLY

70. Collect the valve and spring assembly components, as shown in (Fig. 70) on a clean surface and note carefully the following:

- (a) The hollow portion of the pressure regulator valve faces the valve spring.

(b) The valve spring assembles into the pressure regulator valve.

(c) The concave portion of the valve spring retainer assembles over the valve spring.

71. After carefully checking the pressure regulator valve and the bore in the forward and reverse gear transmission valve for dirt and burrs, assemble all valve and spring components shown in (Fig. 70).




Fig. 71 Control Valve Assembly in Fixture

72. Place the assembled parts in a suitable assembly fixture, (Fig. 71). Turning handle of threaded plunger, compress the regulator valve spring until the groove for the snap ring in the pressure regulator valve is fully exposed. Install snap ring shown in (Fig. 71). The "O" ring shown in (Fig. 70) should be installed on end of valve.

NOTE: The control valve assembly can also be assembled by using an arbor press with suitable tools, as shown in (Fig. 72).




Fig. 72 Installation of Snap Ring

INSTALLATION OF THE VALVE AND SPRING ASSEMBLY IN THE TRANSMISSION CASE

73. Place parts assembled in steps 1 through 69 inclusive, on clean flat surface. Into the opening provided high on the right-rear side of the transmission case, place the valve and spring assembly, threaded end entering first, (Fig. 73). This is a hand assembly and is completed when the valve and spring assembly "bottoms" against the shoulder in the case bore.




Fig. 73 Installation of Valve and Spring Assembly




Fig. 74 Assembly of Valve Cover




Fig. 76 Shift Lever Assembled

ASSEMBLY OF SHIFT LEVER

74. To insure neutral positioning of valve and easier assembly of lever, align .369-.376 width slot in valve with bottom 1/4-20 bolt hole in valve cover face of case as shown in (Fig. 73).
75. Assemble the valve cover gasket, valve cover, lockwashers and hex head bolts as indicated in (Fig. 74). Torque hex head bolts to 8-11 pounds-feet.

76. Assemble shift lever and related parts in the order shown in (Fig. 75). Torque the hex nut 8 to 11 pounds-feet, (Fig. 76). Rotation of the valve and spring assembly through the forward, neutral and reverse positions should require no more than fingertip effort. If valve binds in rotation, remove and inspect.




Fig. 75 Assembly of Shift Lever and Related Parts




Fig. 77 Installing Oil Strainer & Cooler Return Tube & Bushing Assembly

INSTALLATION OF OIL STRAINER ASSEMBLY AND OIL DRAIN PLUG INTO TRANSMISSION CASE

77. Assemble the oil strainer assembly, cooler line return bushing and cooler return tube assembly in the order shown in (Fig. 77). The screen end of the oil strainer assembly should be approximately 1/2 inch below the face of the case when the assembly is correctly installed.
78. Tighten cooler line return and oil drain bushing to recommended torque of 25 to 35 pounds feet.

INSTALLATION OF MISCELLANEOUS TRANSMISSION PARTS

79. Install the breather assembly as shown in (Fig. 78). Do not hammer on the top of the breather assembly illustrated as this will damage the sealing element. For installation of other type breather assemblies see page 48, (paragraphs 3 & 4) for instructions.




Fig. 78 Installation of Breather Assembly




Fig. 79 Installation of Dip Stick Assembly

80. Install the dipstick assembly as shown in (Fig. 79) and tighten to a torque sufficient only to prevent oil leakage (approximately 10-15 pounds-feet).
81. Install 3/8-18, 1/4-18 and 1/8-27 dryseal plugs, (Fig. 80) and torque to values indicated on page 62.




Fig. 80 Installation of Miscellaneous Pipe Plugs

EXTRA EQUIPMENT

ASSEMBLY OF NEUTRAL SWITCH KIT

1. Unscrew three (3) hex head bolts, remove valve cover and gasket, as shown in (Fig. 74). Discard valve cover, gasket, hex head bolts and lockwashers.
2. Shift control lever into neutral position, see page 23 (Fig. 17). Assemble gasket provided in neutral switch kit. Assemble neutral switch cam, making sure to align tang "A" on cam with slot "B" in valve, as




Fig. 81 Neutral Switch Parts

shown in (Fig. 82). Neutral switch cam correctly assembled as shown in (Fig. 83).

3. Assemble valve cover and neutral switch with neutral switch located between two (2) top 1/4-20 bolts, as shown in (Fig. 84). Use the three (3) 1/4-20-7/8 inch long hex head bolts provided in neutral switch kit. Tighten hex head bolts to recommended torque of 8 to 11 pounds-feet and assemble starter solenoid wires to switch.




Fig. 83 Neutral Switch Cam in Correct Position



Fig. 82 Assembly of Neutral Switch




Fig. 84 Neutral Switch Correctly Assembled

SPECIAL INFORMATION AND INSTRUCTIONS

MODEL 70C & 71C TRANSMISSIONS

NOTE: It may be found that in a Model 70C or 71C transmission assembly a number of components may vary from the description and illustrations presented in the preceding portion of this manual. This results from changes which have been made since the first introduction of this model. In this section the information and description is presented for those features which are no longer incorporated in the current production models.

INSTALLATION OF OIL FILLER CAP AND DIP STICK ASSEMBLY

1. Place oil filler cap and dipstick assembly in the oil filler tube provided on rear left side of transmission case, (Fig. 85). Push down on filler cap and dipstick until assembly "bottoms" on tube, then turn cap to right as far as cap screw permits.




Fig. 85 Installation of Oil Filler Cap and Dipstick Assembly

INSTALLATION OF OIL STRAINER ASSEMBLY AND OIL DRAIN PLUG INTO TRANSMISSION CASE

2. Assemble the oil strainer assembly (71B-A98) and cooler line return bushing (4885A) in the order shown in (Fig. 86). The small end of oil strainer assembly should protrude out of tapped hole in case approximately 1/16 inch when installed to full depth.

NOTE: Bushing (4885B) illustrated in (Fig. 77) as used with present oil strainer assembly, may be used with the old oil strainer assembly (71B-A98) shown in (Fig. 86). On the other hand, the old bushing (4885A) is not threaded the entire length of its internal thread. Therefore, it cannot be assembled with the cooler return tube (71C-84 shown in (Fig. 77)). Either complete assembly of parts, illustrated in (Fig. 77) or (Fig. 86), can be used as they are interchangeable.




Fig. 86 Installation of Oil Strainer Assembly and Cooler Line Return Bushing




Fig. 87 Installation of Breather Assembly



Fig. 88 Adapting Breather Assemblies




Fig. 89 Pump Porting in 71B-8 Adapter

INSTALLATION OF BREATHER ASSEMBLY

3. In addition to the breather assembly shown in (Fig. 78), other breather assemblies will be found in use as illustrated in (Fig. 87) and (Fig. 88). The above illustrations demonstrate the manner in which these breather assemblies are installed.
4. The breather in (Fig. 88) is supplied for those installations where a pressure type breather replaces the breather shown in (Fig. 87). This breather is used with an internally threaded bushing which presses into the case before the installation of the threaded breather assembly.

ASSEMBLY OF FRONT PUMP

NOTE: The following instructions are for the assembly of the front pump with a backing plate, (Fig. 91). This pump can be used with either of the two different adapter housings, but it should normally be found assembled on the one shown in (Fig. 89). Any of the various versions of the input shafts may be used with this pump, but the proper key must always be used with each shaft. See (Fig. 90) for comparison of the installation of the two pump assemblies and information on the other related parts.




Fig. 90 Illustration of the Installation of the Two Types of Pump Assemblies and Their Related Parts.

5. Collect the parts shown in (Fig. 91) and check carefully for the following:

- (a) Scoring in gear pockets, crescent, backing plate and gear faces.
- (b) Dents and burrs on both faces of backing plate.
- (c) Oil seal lip for brittle condition, cracks and cuts. Oil seal outside diameter for dents or scratches.
- (d) Gear teeth for burrs.

6. Place pump housing squarely on arbor press table. Apply a suitable sealant to the outside diameter of seal before installing squarely into bore of housing with seal lip positioned as shown in (Fig. 92). Caution should be observed to insure that too much sealant is not used, that any excess is wiped away after the seal is installed, and that the sealant does not get on the sealing element.
7. Using an arbor press and suitable tool, press seal into housing until front face of seal is flush with front face of pump housing, (Fig. 93).
8. Place housing, lubricated with automatic transmission fluid type "A", suffix "A", and complete with seal in position shown in (Fig. 94). Install lubricated gears as shown, with reassembly identification marks matched, (Fig. 94).




Fig. 91 Front Pump Parts with Backing Plate, Assembly 71-1A60




Fig. 92 Installing Oil Seal




Fig. 93 Pressing Oil Seal




Fig. 94 Installing Pump Gears




Fig. 95 Installing Backing Plate




Fig. 96 Installing Flat Head Machine Screw through Backing Plate




Fig. 97 Mounting Front pump

9. Inspect both faces of backing plate for dirt, lubricate and assemble, as shown in (Fig. 95).
10. Install the flat head machine screw and tighten to final torque of 25 to 35 pounds-inch, (Fig. 96). Check rotation of gears as assembled in pump housing; disassemble and inspect if gears do not turn freely.

MOUNTING FRONT PUMP ON TRANSMISSION

11. Place assembled transmission on rear face of coupling in upright position, as shown in (Fig. 97). Inspect upper exposed adapter face for dirt and obstructions, then lubricate and install front pump gasket.

12. Install Woodruff key.

NOTE: Check (Fig. 90) to determining that proper key and shaft are used.

13. Use a suitable tool to cover the splined portion of the input shaft and thereby protect the rubber lip on the oil seal during assembly of front pump, (Fig. 97).

14. After checking the following items, place the front pump assembly, steps 5 through 10 inclusive, squarely down over the protruding input shaft and assembly tool, (Fig. 97).

- (a) Alignment of Woodruff key slot in drive gear with mating Woodruff key on the input shaft.
- (b) Orientation of pump mounting bolt holes and direction of rotation arrow, depending on desired direction of input rotation, (Fig. 98 or Fig. 99).
- (c) Freedom of rotation of pump gears in housing.

NOTE: The location of the markings on the 71-60 pump housing identifying the orientation of the pump assembly on the adapter for right or left hand rotation will vary depending upon which pump assemblies and adapters are used.

The newer pump assembly with backing plate, identified by the rib on the pump housing, will be properly mounted when the marking on the pump housing appears as shown in (Fig. 98), when mounted on the 71-8B adapter, (Fig. 89). If the same pump were mounted on the new adapter 71C-8, (Fig. 61), the pump markings would be identical to those illustrated for the new 71C-A60 pump assembly in (Fig. 68).

The older pump assembly with backing plate, identified by the absence of the rib on the 71-60 pump housing, would appear as illustrated in (Fig. 99) when mounted on the old 71-8B adapter (Fig. 89). This older pump assembly with backing plate could also be mounted on the new 71C-8 adapter (Fig. 61), but this has not been illustrated as no original factory installations were made in this manner.




Fig. 98 Orientation Markings for New 71-1A60 Pump Assembly on 71-8B Adapter




Fig. 99 Orientation Markings for Old 71-1A60 Pump Assembly on 71-8B Adapter

15. With front pump assembly resting squarely on gasket and seal assembly tool removed, install four (4) 1-7/8 long hex head bolts, (Fig. 100). Tighten hex head bolts evenly to torque of 17 to 22 pounds-feet.

ELIMINATION OF REGULATOR VALVE BUZZ

16. New pressure regulator valves (71-243) have a relief at the outer diameter at the closed end for the elimination of regulator valve buzz, (Fig. 101). If a transmission should have a valve buzz and contains a 71-243 pressure regulator valve which does not have the relief, the valve should be replaced, or reoperated as illustrated.




Fig. 100 Bolting Front Pump Assembly




Fig. 101 Reoperation to Eliminate Regulator Valve Buzz




Fig. 102 Versions of Drive Gear and Plug Assemblies




Fig. 103 Pinion Cage and Output Shaft Assembly with Oil Grooves

DRIVE GEAR AND PLUG ASSEMBLIES

17. The two methods of sealing the end of the drive gear are illustrated in (Fig. 102). Sketch "B" illustrates the method now used and sketch "A" the method formerly used. The two drive gear assemblies, varying only in the method of sealing the end of the shaft, are fully interchangeable.

PINION CAGE AND OUTPUT SHAFT ASSEMBLY

18. Pinion cage and output shaft assembly has been supplied with three oil grooves around the shaft diameter as shown in (Fig. 103). This shaft can be used to replace any shafts. However, shafts without the grooves must not be used with those forward and reverse transmission cases supplied without the 71-28B bushings.

FORWARD AND REVERSE GEAR TRANSMISSION CASE AND BUSHING ASSEMBLY

19. Two versions of the transmission case have been supplied; one includes bronze bushings for the output shaft journal, the other is designed for use without the bushings. These two versions of the transmission case are completely interchangeable, except that the case without bushings cannot be used with the output shaft assemblies which do not have the oil groove (Fig. 103). Information regarding the service replacement of case bushings can be found on page 59, (Fig. 111). If it becomes necessary to replace a case of the design without bushings because of worn journals, it can be returned to your engine supplier. He can return the case to Warner Gear for reoperation and installation of bushings and can furnish information concerning the cost of this service.

SPECIAL INFORMATION AND INSTRUCTIONS

MODEL 70B & 71B TRANSMISSIONS

NOTE: Except for the discussions and illustrations on the features included in this section all other information concerning the Model 70B and 71B Transmissions may be found in preceding sections of the manual containing information for the assembly or disassembly of the Model 70C and 71C Transmission, or in the special supplementary section for these transmissions, pages 47 to 52.

INSTALLATION OF BREATHER ASSEMBLY

1. Assemble the screw-in type breather assembly as shown in (Fig. 104).

ASSEMBLY OF FRONT PUMP

2. The pump assembly for the Model 70B and 71B transmissions (71-A60) contains a different seal than the pump assembly with backing plate for the Model 70C and 71C (71-1A60). They are identical in all other respects. Therefore, when assembling the front pump assembly 71-A60 follow the information in (paragraphs 5-15) pages 48 to 51, with the exception that the seal should be pressed into the pump housing until front face of seal is 1/8 inch above front face of pump housing, (Fig. 105).




Fig. 104 Installation of Breather Assembly

DRIVE GEAR & PLUG ASSEMBLY

3. The drive gear assembly has a different input drive spline. For other instructions see page 52, (paragraph 17).

ASSEMBLY OF SHIFT LEVER

4. For assembly of shift lever see page 44, (paragraph 76). The assembly procedure is the same for the Model 70B and 71B Transmissions as that described and illustrated for the Model 70C and 71C. Although the




Fig. 105 Pressing Oil Seal




Fig. 106 ASI-71B & ASI-70B Shift Lever Positions

present shift lever (71-79B), (Fig. 17), can be substituted for the lever shown in (Fig. 106), it would change the travel of the control linkage for shifts between "Neutral" and "Forward" positions, see (Fig. 17) and (Fig. 106).

SPECIAL INFORMATION AND INSTRUCTIONS MODEL 70 & 71 TRANSMISSIONS

NOTE: Except for the discussions and illustrations on the features included in this section all other information concerning the Model 70 and 71 Transmissions may be found in the manual information for the assembly or disassembly of the Model 70C and 71C Transmission, or in the special supplementary sections, pages 47 to 53.

ASSEMBLY OF FRONT PUMP

1. On early production Model 70 and 71 transmissions the overall height of the pump housing between faces measured 1-7/8 inches instead of 1-5/8 on all other latter pump assemblies. For any pump housing having the 1-7/8 inch dimension, assemble the seal 1/8 inch below appropriate pump face. For all other information regarding the front pump see page 53, (paragraph 2).




Fig. 107 Installing Baffle

ADAPTER CAPSCREWS

5. The 3/8-16x1-1/4 hex socket cap screws (138243) formerly used to fasten the adapter to the transmission case have now been replaced with a twelve (12) point cap screw (4911) which has better locking characteristics. The two types are completely interchangeable.

INSTALLATION OF THE BAFFLE IN THE TRANSMISSION CASE

2. Place the baffle inside the transmission case with the curved portion below the cast spherical bosses in the case as shown in (Fig. 107). Also refer to (Fig. 6) and (Fig. 7).
3. Position the front end of the baffle so that the center of the baffle rests on top of the boss at the front center of the transmission case and the turned down corners of the baffle are located below the cast spherical bosses at the front of the transmission case.

Snap the baffle into position by lifting up on the curved portion so that the two large holes are located firmly on the spherical bosses at the rear of the transmission case as shown in (Fig. 107).




Fig. 108 Installation of Oil Drain Plug and Related Parts

INSTALLATION OF OIL STRAINER ASSEMBLY AND OIL DRAIN PLUG INTO TRANSMISSION CASE

4. Using the oil strainer assembly, annular gasket and oil drain plug as shown in (Fig. 108) proceed as follows:

- (a) Insert the oil strainer into the tapped hole provided in the lower-right side of the transmission case. The end of the oil strainer assembly will be approximately 1/2 inch below the finished face of the case boss when properly assembled.

- (b) Mount the annular gasket on the oil drain plug and screw the oil drain plug into the case drain hole. Tighten plug to a torque of 25-35 pounds-feet.

NOTE: The oil strainer assembly 71C-A98A shown in (Fig. 108) has replaced a similar oil strainer assembly 71-A98C, but these two parts are fully interchangeable. However, oil strainer assembly 71-A98, with

the closed end and wire ring, should not be confused with either of the two above oil strainer assemblies. It can only be used when cooler return flow does not return through the oil strainer assembly.






COOLER RETURN TO TRANSMISSION

5. On the Model 70 and 71 transmissions it is now recommended that the cooler oil flow be returned to the transmission case as shown in (Fig. 1). Transmissions with the cooler flow returning in a manner other than that now recommended need not be changed. However, the arrangement now recommended conforms to practices followed on other transmission installations and permits better control of the cooler return oil flow to the pump suction.

NOTE: If cooler return flow is changed to the new location be sure that the oil strainer installed is similar to the one illustrated in (Fig. 108). The old strainer assembly with one end enclosed would block the flow of the cooler return oil.

TORQUE SPECIFICATIONS

PART NUMBER	DESCRIPTION	APPLICATION	TORQUE LBS.- FT.
179822	5/16-18 x 1-1/2 HEX HEAD BOLT	PUMP TO ADAPTER	17-22
4911	3/8-16 x 1-1/4 12 POINT CAPSCREW	ADAPTER TO CASE	27-37
179793	1/4-20 x 5/8 HEX HEAD BOLT	VALVE COVER TO CASE	8-11
115729	5/16-24 NUT	SHIFT LEVER TO VALVE	8-11
179859	7/16-14 x 1-1/4 HEX HEAD BOLT	BEARING RETAINER TO CASE	27-32
4775L	1-20 NUT	OUTPUT SHAFT NUT	100-200
4885B	3/4-14 BUSHING	COOLER RETURN TO CASE	25-35
444687	1/8-27 DRYSEAL PIPE PLUG	CASE	7-12
444691	1/4-18 DRYSEAL PIPE PLUG	ADAPTER	12-20
444866	3/8-18 DRYSEAL PIPE PLUG	CASE	17-27
71-A195	3/4-14 PIPE PLUG	DIPSTICK ASS'Y. INTO CASE	10-15



The assembly tool drawings shown on this page are included to illustrate how these tools may be made. Most will provide convenience in assembling and disassembling the transmission and their functions may be performed by the substitution of other objects or pro-

cedures. However, the use of the oil pump assembly tool, or other means of protecting the seal lip, is a necessity.

The drawings are provided as a convenience.

WARNER GEAR DOES NOT MANUFACTURE OR SELL ANY OF THE TOOLS ILLUSTRATED.

*NOTE #4

Subject: Velvet Drive Reverse Clutch Plates.

CHART LISTING REVERSE CLUTCH PLATES

PART NUMBER	DESCRIPTION	PLATE THICKNESS	
		Inch	mm
71-86 (1)	Fiber	247-.252	6.27-6.40
72-A66	Sintered Copper	0605-.063	1.54-1.60
72-A66B	Sintered Copper	1135-.116	2.88-2.95
10-17-666-001	Cellulose	113-.118	2.87-3.00
72-176	Steel	0665-.071	1.69-1.80

(1) No longer available from Warner Gear.

The following chart will simplify the selection of the correct reverse clutch plates for field servicing of Velvet Drive transmission. The reverse clutch cavity depth should be measured and a suitable clutch plate and dowel combination should be selected according to the model and cavity depth as shown in the following chart. The new cellulose plates 10-17-666-001 are recommended, however proper combinations of earlier clutch plates can be used.

COMBINATION

	TRANSMISSION MODEL	CLUTCH CAVITY DEPTH		PART NUMBER OF PLATES	NUMBER REQ'D.	OTHER COMBINATIONS
		Inch	mm			
1	70 & 71 All	.782	19.9	71-86 71-87 dp*	1 3	2 or 10
2	72 Direct Drive	.782	19.9	72-A66 72-176 71-87 dp*	2 1 3	None
3	71 Reductions 72 Direct Drive	.857	21.8	72-A66B 72-176 R6-177 dp*	2 1 3	8
4	72 Reductions	1.074	27.3	72-A66B 72-176 4622E dp*	3 2 3	9
5	72 Reductions	.911	23.1	72-A66 72-176 71-87 dp*	3 2 3	None
6	71 Direct Drive	.646	16.4	72-A66B 71-87A dp*	1 3	7
7	71 Direct Drive	.646	16.4	10-17-666-001 71-87A dp*	1 3	6
8	71 Reductions 72 Direct Drive	.857	21.8	10-17-666-001 72-176 R6-177 dp*	2 1 3	3
9	72 Reduction	1.074	27.3	10-17-666-001 72-176 4622E dp*	3 2 3	4
10	70 & 71 All	.782	19.9	10-17-666-001 72-176 71-87 dp*	1 2 3	1

*dp = dowel pin

All kits have been discontinued except for the following:

A4867AB
A4867AE
A4867DD
A4867HA
A4867VV
A4867HB

A4867HS
A4867DW
A4867HN
10-04-420-052
10-95-410-002
10-13-410-001
10-13-410-002
13-08-410-001

"72C" Forward Clutch Pack Kit
"71C" Forward Clutch Pack Kit
Output Shaft Bushing Kit
Oil Seal & Sealing Ring Kit
Case Bushing Kit
Gasket, Oil Seal & Sealing Ring
Kit for "73C"
Pilot Light Kit
Small Parts Kit for "73C"
Drive Gear Alarm Kit
Neutral Switch Kit
Snap Ring Kit for All 70C, 72C,
& 72C Units
Gasket & Seal Kit for All CR2 Units
Small Parts Kit for CR2 Units
V-Drive Overhaul Kit

Deniz Motor Tamir Atölyesi
İbrahim Çemberci
Büyükdere, Kırklar Sok. No. 7
İSTANBUL
Tel. 142 1917-142 01 51

Individual parts may still be purchased from kits that have been obsoleted even though the kits will no longer be serviced. Use kits 10-95-410-002 and A4867HA to replace kit A4867WW.